

Dual Radio Microphone User Guide



The following Lecture Theatres and CATS (Centrally Allocated Teaching Spaces) now have Dual Radio Microphones available:

A

Ainsworth (Building J17)

- › [Theatre G03](#)

AGSM (Building G27)

- › [Hugh Dixson Theatre](#)

B

Business School (Building E12)

- › [Room 105](#)
- › [Room 115](#)
- › [Room 119](#)
- › [Room 130](#)

C

Central Lecture Block (CLB) (Building E19)

- › [Theatre 1](#)
- › [Theatre 2](#)
- › [Theatre 3](#)
- › [Theatre 4](#)
- › [Theatre 5](#)
- › [Theatre 7](#)

Colombo (Building B16)

- › [Theatre A](#)
- › [Theatre B](#)
- › [Theatre C](#)
- › [Room LG02](#)
- › [Room LG03](#)

L

Law (Building F8)

- › [Room G02](#)
- › [Room G17](#)
- › [Room G23](#)

M

Mathews Theatres (Building D23)

- › [Theatre A](#)
- › [Theatre B](#)
- › [Theatre C](#)
- › [Theatre D](#)

Mathews (Building F23)

- › [Room 101](#)
- › [Room 102](#)
- › [Room 103](#)
- › [Room 104](#)
- › [Room 105](#)
- › [Room 227](#)
- › [Room 228](#)
- › [Room 310](#)

Q

Quadrangle (Building E15)

- › [Room G025](#)
- › [Room G026](#)
- › [Room G027](#)
- › [Room G034](#)
- › [Room G040](#)
- › [Room G053](#)
- › [Room 1001](#)
- › [Room 1043](#)
- › [Macauley Theatre](#)

R

Rex Vowels Theatre (Building F17)

- › [Room LG3](#)

T

Tyree Energy Technology (Building H6)

- › [Theatre LG03](#)
- › [Theatre LG05](#)
- › [Theatre LG07](#)
- › [Room G16](#)

Dual Radio Microphone User Guide



Please note:

The original Belt Pack (Shure SL4) will no longer work in these Teaching Spaces.


To Use:

- › Simply take out of the charging cradle and use as per User guide lines for previous Belt Pack.
- › To use the Hand-Held Microphone take it out of the charging cradle and speak into it.
- › If there is no sound, make sure the transmitter is turned on before calling Support.

After Use:

Make sure to replace the Belt Pack and /or Hand-Held Microphone in to the charge cradle, making sure the charging indicator lights up for the next user.

When finished, **return the microphone to the charge cradle**, making sure the **red charge light switches on**.



Handy Tip: Leave the microphone switched on when returning it to the charger – it will automatically turn off.



Technical Support:

Please call ext. **54888** from the help phone located on the lectern.